ocee DESIGN

User Guide 1.0

Ocee Design Forum

Content creator | Diane Butterworth | www.dianebutterworth.com

Ocee Design. Forum

Content Creation Sheet

Date: 26.11.15

Revision: 1.0

Contents

Page Number	Data Sheet
0	Predefined Types
1	Straight
2	Convex
3	Concave
4	Table
5-7	User Guide

ocee DESIGN

Forum. Straight

Predefined Types

Family Type	Width	Depth	Height
Armchair	780	820	890
Chair	580	820	890
Chair with Left Arm	680	820	890
Chair with Right Arm	680	820	890

Material Options

Range of Fabric	Seat and Back Fabric

ocee DESIGN

Forum. Convex

Predefined Types

Family Type	Width	Depth	Height
Convex Corner	490	820	890

Material Options

Range of Fabric

Seat and Back Fabric

ocee DESIGN

Forum. Concave



Predefined Types

Family Type	Width	Depth	Height
Concave Corner	680	820	890

Material Options

Range of Fabric

Seat and Back Fabric

ocee DESIGN

Forum. Table



Predefined Types

Family Type	Width	Depth	Height
Table	770	770	300

Material Options

Range of Fabric

Base Fabric

Table Finish

ocee DESIGN

Forum. Your Revit Guide

A simple guide to using Ocee Design Revit Ready files.

1. LOAD IT

The Forum range consists of 4 Revit Families, this contains predefined types as outlined above in the predefined types and the manufactures brochure.

After downloading and saving the file to a suitable location go to ‘Insert Tab/Load Family…’



Forum. Your Revit Guide

2. USE IT

Once your family is loaded in, it will be located in the ‘Project Browser/Families/Furniture’ tab. Types are named in a way to ensure ease of selection. Click and drag your chosen item into your floor plan.



3. CUSTOMISE IT

Once an item is selected it will turn blue, the properties panel will then display the parameters available. Here you will be able to make changes to the finishes. All material options will load in with the family, click the ‘materials and finishes’ parameter to view.

Please note— The fabric type will determine the fire rating. Please complete ‘FireRating’ Parameter once selection has been made.